



Technical installation instructions for Repetit in combination with grout



Showroom and Offices
Via San Pietro, 4
41121 Modena - Italy
T +39 059 4270330
F +39 059 2154763

Registered Office
Via San Pietro, 4
41121 Modena - Italy
info@opificioceramico.com
opificioceramico.com

Opificio Ceramico Srl
Cap.Soc. i.v. 62.500 - N. REA 421093
Reg. Imp. MO C.F. 03827700364
P. IVA/VAT N. IT-03827700364
Codice univoco T04ZHR3

Required equipment

- A. Trowel of approximately **600 g**



- B. Rubber spatula



- C. Float



- D. Electric mixer with low speed setting



Preparation of the substrate

1. Glue REPETIT onto a perfectly flat and leveled substrate.
2. Use adhesive suitable for porcelain stoneware.
3. Ensure that the tiles are laid following the orientation indicated on the boxes.
4. For optimal results, it is recommended to lay the tiles edge to edge without using spacers. It is also possible to use spacers provided by Opificio Ceramico; in this case, consult the company in advance for supply and usage instructions.
5. Allow the adhesive to dry completely.
6. Proceed with grouting, completing one wall at a time.

Epoxy Grout Application

1. Prepare the grout following the instructions provided by MAPEI. During this process, it is essential to use a low-speed electric mixer (D) for at least 60 seconds.
2. Proceed with grouting using a rubber spatula (B). Compact the material well by applying even pressure. Work on a surface of 0.5×0.5 meters at a time—no more—so that the grout to be removed is still very soft. No more than 10–15 minutes should pass between grouting and cleaning.
3. We recommend adding a water- and oil-repellent solution, such as FILA W68 (15% of the total), to a bucket of clean water and wetting the float (C) with this mixture to make cleaning small grout residues easier. Use gentle movements without pressure and without removing grout from the base of the tile. Cleaning with the float can also be done using plenty of perfectly clean water alone